

RACK WENDESDAY NIGHT INSTALLATION INSTRUCTIONS

Mounting Steps:

1. Assemble the rack body using 6 pieces of M5x12 bolts.
2. Depending on the distance between the frame end eyelets, use M5x22 bolts & distance washers to attach the rack body to the eyelets.
3. Attach the mounting kits and aluminum struts to the rack body using 2 pieces of M5x12 bolts and washers.
4. Depending on the distance between the rack and the seatstay M5 mounts, use M5x12 bolts to attach the aluminum struts to the frame.
If necessary, trim any excess aluminum struts.
5. Adjust the rack to the desired location and then securely tighten all the bolts.

Requirement:

1. Front M5 mounts on the frame seatstay.
2. Rear M5 eyelets around the frame end.
3. The rear spacing between rack mounting points is 170mm.
Longer M5 bolts and distance spacers of various lengths are included.
4. For size M (26" to 28"): The distance between the eyelets' center to tire thread requires less than 345mm (without fenders).
5. For Size L (29"): The distance between eyelets' center to tire thread requires less than 370mm (without fenders).

